



<u>www.sadef.com</u> sadef.flexroof@voestalpine.com

by voestalpine <u>DESIGN FORM</u>				
COMPANY:	PROJECT:			
Contact:	Location:			
Function:	Google-Earth			
Tel.:	coord.:			
E-Mail:	Altitude of terrain:			
PROJECT STADIUM				
□ OFFER	Expected Offer Date:			
ORDER	Expected Delivery on site:			
1. Solar Configuration	2. Foot and Ballast			
A) Please add final lay-out of roof with PV-modules (DWG format).	FastFoot			
B) Please add datasheet of used PV-	Dimensions: 350x190x40mm			
module or specify below:	Weight: 6,1kg			
Brand:	☐ Use as Foot			
Type:	☐ Use as Ballast			
Dimensions :	☐ If you are using other than FastFoot,			
Height:[mm]	please specify:			
Width:[mm]	Foot Ballast			
Length:[mm]	Length			
 Weight :[kg]	Width			
	Height			
	Weight			
3. Roof Geometry A) Please add roof geometry (DWG format) or specify below:	4. Loads and other info A) If location is Belgium, Netherlands, France, Germany or UK, loads will be			
Building Dimensions (if rectangular shape):	defined by Sadef following Eurocode.			
Height of Building (Hr):[m]	If other location please specify:			
Height of Parapet (Hp):[m]	- Characteristic Snow Load on the			
Length:[m]	ground (kg/m²)			
Width:[m]	- Peak velocity wind pressure (Pa)			
Roof slope:° □ North-South direction □ East-West Direction	B) Terrain Category:			
Friction coefficient (µ): Max acceptable weight of solar installation: [kg/m²]	C) If there exists in the neighbourhood a building minimum twice as high as the			
B) Please specify roof covering:Steeldeck - EPDM - PVC - TPO	building with FlexRoof installation, please fill in:			

Mechanically fastened: yes/no

Height neighbouring building:

Distance to FlexRoof installation:[m]





5. Flexroof South System Geometry

X1 = distance bolt to bolt under triangle

X2 = distance bolt to bolt between 2 triangles

X3 = row distance





Select preferred slope and define your row distance and free walking space (*):

Please circle preferred triangle slope α	Module width (mm)	X1 (mm)	Please specify "pitch" or row distance X3 = X1 + X2
10°	980-1010	1300	
	1011-1052	1350	
	1053-1090	1400	
	1091-1130	1450	
	1131-1170	1500	
13°	980-1010	1250	
	1011-1052	1300	
	1053-1090	1350	
	1091-1130	1400	
	1131-1170	1450	
15°	980-1025	1300	
	1026-1070	1350	
	1071-1110	1400	
	1111-1150	1450	

(*) free walking space = X2 minus ca. 50 mm





6. East-West-System Geometry

X1 = distance bolt to bolt under triangle

X2 = distance bolt to bolt between 2 triangles

X3 = row distance





Select preferred slope and define your row distance and free walking space (*):

Please circle preferred triangle slope α	Module width (mm)	X1 (mm)	Please specify "pitch" or row distance X3 = X1 + X2
10°	980-1016	2050	
	1017-1044	2100	
	1045-1070	2150	
	1071-1095	2200	
	1096-1120	2250	
	1121-1145	2300	
15°	980-1016	2000	
	1017-1044	2050	
	1045-1070	2100	
	1071-1095	2150	
	1096-1120	2200	
	1121-1145	2250	

(*) free walking space = X2 minus ca. 50 mm